How to upgrade firmware version 2.00 (or newer) in 2 steps

Please upgrade the firmware in 2 steps for security improvement.

Encrypted firmware: the file name shows "sfv311A_200ES.zip" (with "S"), as an example.
Unencrypted firmware: the file name shows "sfv311A_193E.zip" (without "S").

You have to upgrade version 9.99 once, then upgrade 2.00 (or newer).

Impossible to upgrade to version 2.00 (or newer) directly (without upgrading ver. 9.99).



Once upgrade to version 2.00 (or newer), possible to downgrade.

In a case appearing "Safe mode", please upgrade version 9.99 again or version 2.00 (or newer) directly depends on the situation as follow;

A. When you see the "Safe mode" without showing "Decryption support", please upgrade version 9.99 again then version 2.00 (or newer).



When you see the "Safe mode (Decryption support)", you can upgrade version 2.00 (or newer) without upgrading version 9.99.



B.